

# S-RMS


S-RMS is WEB application on IOT Linker.

The S-RMS application can be accessed via any web browser.

Access is always possible via the local network (via the IP address of the IOT Linker).

For remote access via the Internet, it is necessary to allow the WEB-SSH functionality. In this case, the IOT-Linker connects to Robotina's "hiq-space.com" WEB-SSH server via a secure SSH connection. On WEB-SSH server each IOT Linker gets its own web address of the type <https://12345.hiq-space.com> (12345 is the serial number of the IOT Linker). This makes it possible to access the WEB interface via a secure https connection via the Internet without directly exposing the IOT Linker to the Internet.

## Log-in



Enter Username, Password and press Log in button.

## Room group overview

The screenshot displays the S-RMS Room group overview for HIQ Hotel. The interface is annotated with numbered callouts 1 through 6:

- 1**: Application logo (S-RMS)
- 2**: Pages tabs (Main, Search codes, User Accounts, Access Settings, General Settings, Diagnostics)
- 3**: User menu (Demo Admin)
- 4**: Tree view (room groups and rooms)
- 5**: Group picture (HIQ Hotel logo with tagline "Where Hospitality Meets Innovation")
- 6**: Rooms overview table (basic room statuses)

Room	Booked	Presence	DND	MUR	SOS	Fire alert	HVAC status	Setpoint	Fan limit	Mesured	Fan speed
Room 707	not booked	empty	idle	idle	idle	idle	heat idle	10.0 °C	OFF	12.7 °C	OFF

© Robotina d.o.o all rights reserved (except for included oss software). 1.9 / 1.65 / 1.10.dev

1	Application logo (customizable)
2	Pages tabs (pages that are available for the selected space in the tree structure)
3	User menu (user logout and help)
4	Tree view (room groups and rooms)
5	Group picture (floor plan, logo, ...)
6	Rooms overview table (basic room statuses)

## Room overview

The screenshot displays the S-RMS room control interface for Room 707. The interface is organized into a grid of 19 numbered controls, each with an icon and a label. The controls are as follows:

- 1**: Booked status (click to toggle)
- 2**: Presence status (click to toggle)
- 3**: DND status (click to toggle)
- 4**: MUR status (click to toggle)
- 5**: SOS status (click to toggle)
- 6**: Fire alert status (click to toggle)
- 7**: Managed power supply status (click to toggle)
- 8**: Ventilation status (click to toggle)
- 9**: Wake up status (click on icon to toggle, click on time to set time)
- 10**: Wake-up scene enable (click to toggle)
- 11**: Light status (click to toggle)
- 12**: Dimmer status (click on icon to toggle, set slider to adjust brightness)
- 13**: Blinds status (set slider to move, click on icon to stop)
- 14**: All Off status (click to toggle)
- 15**: HVAC mode (click to toggle)
- 16**: HVAC status (click to toggle)
- 17**: Measured temperature (5.9 °C)
- 18**: Fan speed (click to toggle)
- 19**: HVAC setpoints table

The HVAC setpoints table is as follows:

	Limits	Idle	Booked	Guest	Night (offset)
cooling	10.0 °C 10.0 °C	10.0 °C	10.0 °C	10.0 °C	0.0 °C
heating	10.0 °C 10.0 °C	10.0 °C	10.0 °C	10.0 °C	0.0 °C
fan	-	OFF	OFF	OFF	OFF

© Robotina d.o.o. all rights reserved (except for included oss software). 1.9 / 1.65 / 1.10.dev

1	Booked status (click to toggle)
2	Presence status (click to toggle)
3	DND status (click to toggle)
4	MUR status (click to toggle)
5	SOS status (click to toggle)
6	Fire alert status (click to toggle)
7	Managed power supply status (click to toggle)
8	Ventilation status (click to toggle)
9	Wake up status (click on icon to toggle, click on time to set time)
10	Wake-up scene enable (click to toggle)
11	Light status (click to toggle)
12	Dimmer status (click on icon to toggle, set slider to adjust brightness)
13	Blinds status (set slider to move, click on icon to stop)

<b>14</b>	Scene status (click to toggle)
<b>15</b>	HVAC mode (click to set OFF/Heating/Cooling)
<b>16</b>	HVAC status (read only)
<b>17</b>	HVAC measured temperature (read only)
<b>18</b>	HVAC fan speed (read only)
<b>19</b>	HVAC setpoints (click on value to edit)

## Room access

Access Administration for "Room 707"

Buttons: New code, Delete code, Generate QR

Label	Type	Valid from	Valid to
guest 1	Guest	2024-02-02 15:00	2024-02-08 10:00
guest 2	Guest	2024-02-02 15:00	2024-02-08 10:00
cleaner	Staff	Unlimited	Unlimited

© Robotina d.o.o. all rights reserved (except for included oss software). 1.9 / 1.65 / 1.10.dev

<b>1</b>	Click to add new access code
<b>2</b>	Access codes table. Click in row to select existing access code.

The screenshot shows the 'Access Administration' interface for 'Room 707'. It includes a table of access codes and a 'Code detail' modal.

**Access Codes Table:**

Label	Type	Valid from	Valid to
guest 1	Guest	2024-02-02 15:00	2024-02-08 10:00
guest 2	Guest	2024-02-02 15:00	2024-02-08 10:00
cleaner	Staff	Unlimited	Unlimited

**Code detail Modal:**

Buttons: Edit, OK, Cancel

Code: 2137727721 (with 'Enter custom code' button)

Label: cleaner

Type: Staff

Valid from: [empty] ☒ Unlimited

Valid to: [empty] ☒ Unlimited

Enter 255 for unlimited remaining passes

AP label	Remaining	Unit
Room	Unlimited	passes
Main entrance	0	passes
Pool	0	passes
Fitness	0	passes
EV Charging	0	KWh

Callouts: 1 points to the 'cleaner' row in the table; 2 points to the 'Delete code' button; 3 points to the 'Generate QR' button; 4 points to the 'Code detail' modal.

© Robotina d.o.o. all rights reserved (except for included oss software). 1.9 / 1.65 / 1.10.dev

1	Selected access code
2	Click to delete selected access code
3	Click to generate QR code for selected access code.
4	Selected access code details. Click on Edit button to edit selected access code details.

S-RMS - Access Administration

004360.hiq-space.com/gui/main/controllers/access\_codes.html?cid=access\_code\_controller\_01

S RMS

Room Room settings Access Events Settings Demo Admin robotina


HIQ Hotel  
Room 707

### Access Administration for "Room 707"

New code Delete code Generate QR

Label	Type	Valid from	Valid to
guest 1	Guest	2024-02-02 15:00	2024-02-08 10:00
guest 2	Guest	2024-02-02 15:00	2024-02-08 10:00
cleaner	Staff	Unlimited	Unlimited

QR Code



1

### Code detail

Edit OK Cancel

Code 2137727721 Enter code

Label cleaner

Type Staff

Valid from Unlimited

Valid to Unlimited

remaining passes

	Remaining	Unit
Room	Unlimited	passes
Main entrance	0	passes
Pool	0	passes
Fitness	0	passes
EV Charging	0	KWh

© Robotina d.o.o. all rights reserved (except for included oss software). 1.9 / 1.65 / 1.10.dev

**1** Generated access code. Copy image and paste to send code to guest or employee

**Access Administration for "Room 707"**

New code Delete code Generate QR

Label	Type	Valid from	Valid to
guest 1	Guest	2024-02-02 15:00	2024-02-08 10:00
guest 2	Guest	2024-02-02 15:00	2024-02-08 10:00
cleaner	Staff	Unlimited	Unlimited

**Code detail**

Edit OK Cancel

Enter custom code

255 for unlimited remaining passes

AP label	Remaining	Unit
Room	0	passes
Main entrance	0	passes
Pool	0	passes
Fitness	0	passes
EV Charging	0	KWh

© Robotina d.o.o all rights reserved (except for included oss software). 1.9 / 1.65 / 1.10.dev

1	Click to enter custom access code. Always add custom access code for physical RFID cards.
2	Manual access code field.
3	Access code label.
4	Select access code type. The available code types are set for each room separately in the settings.
5	Date / time when the access code becomes valid.
6	Date / time when the access code expires.
7	Choose if the access code has no time to become valid. Such a code is valid from the moment of entry.
8	Choose if the code has no expiration limit. Such a code will be valid until deleted.
9	Table of permissions for the selected access code. The list of available access points is set for each room separately in the settings. Each access point can have a limited number of accesses or it can be unlimited. The access point can also be a charging station for electric cars, where the amount of electricity available (kWh) is set.