

Commissioning

when the charger is mounted (on wall or freestanding set) , properly connected, we can continue with the commissioning.

Strictly follow [Safety instructions](#)!



Once RDC Charger is configured, it does not require further connection to internet or configurator for normal operation !

Configuration

Install and run [RDC Charger](#) on your PC. Use **autodetect** button to discover EVSE in local network. Enter **names**, choose **icons** for all sources and consumers.

Setting device management features

For each consumer we can set:

- **sub**: mark device as a submeter if device is not part of internal network and/or is not connected as intended by default. Energy division for this device will be ignored.
- **man. time**: the time is in minutes for the manual override. It serves to ensure that the user can ensure a minimum validity of the manual switchover.
- **P nominal**: nominal power in watts used for consumers without power sensor. It ensures energy consumption calculation while in active mode.
- **timetable checkbox**: enable or disable the timetable for each device.

meter	sub	output	man.time	P nominal	
PM3-E-D	<input type="checkbox"/>	EVSE inter.	0min		<input checked="" type="checkbox"/>
/	<input type="checkbox"/>	Digital-2	0min	2500W	<input type="checkbox"/>
PM3-I-D	<input checked="" type="checkbox"/>	Digital-3	0min		<input checked="" type="checkbox"/>
/	<input type="checkbox"/>	/	0min		<input type="checkbox"/>
/	<input type="checkbox"/>	/	0min		<input type="checkbox"/>
/	<input type="checkbox"/>	/	0min		<input type="checkbox"/>
/	<input type="checkbox"/>	/	0min		<input type="checkbox"/>
/	<input type="checkbox"/>	/	0min		<input type="checkbox"/>

Enable power sensor from compatible systems

HEMS will automatically detect compatible

- battery systems **eStore** and
- home automation systems **HIQ Home**

which are in the same local network.

Only the first system is detected, if there is more than one it is necessary to enter the NAD number of the desired system manually.

if **eStore** is **enabled**, HEMS will read:

- **grid** power-sensor
- power-sensor for the **first PV Plant** and
- power-sensor of the **first storage** system

From the **enabled HIQ Home** system, HEMS will automatically read the **grid** power-sensor.

Internet access

RDC Charger is connected to the internet via IOT-L2-2 linker.


Digital output

RDC Charger is supporting up to 8 digital outputs by [WR-1](#) module (WR 1..WR 8).

- [HEMS Configurator](#) → settings page, define digital output for consumer (e.g. Digital-2 & Digital-3),

CONSUMERS	icon	consumer management				meter	sub	output	man.time	P nominal	
RDX Charger	Electric car	✓ OK	add	del		PM3-E-D	✗	EVSE inter.	0min		✗
Oil radiator	Radiator	✗ /	add	del		/	✗	Digital-2	0min	2500W	✗
Chiller	Chiller	✓ OK	add	del		PM3-I-D	✗	Digital-3	0min		✗
/	/	✗ /	add	del		/	✗	/	0min		✗
/	/	✗ /	add	del		/	✗	/	0min		✗
/	/	✗ /	add	del		/	✗	/	0min		✗
/	/	✗ /	add	del		/	✗	/	0min		✗
/	/	✗ /	add	del		/	✗	/	0min		✗

- [HEMS Configurator](#) → home page, toggle ON/OFF states for digital-2 and digital-3.




Note: Nominal power **P nominal** is suitable for consumer(s) without connected power sensor. It is used for consumed energy calculation during active mode.

IO mux

[HEMS Configurator](#) → IO mux page allows setting of output types for WR-1 module(s):

- WR 1 → to Router reset, when conditions for router reset are met, WR 1 module will change relay state (turns ON/OFF router wired to WR module),
- or when WR 5 → Digital-2, it means that change of digital2 (consumer 2) reflects on WR 5 relay state.




The screenshot shows the 'IO mux' configuration page. At the top, it says 'Wireless relay WR-1 output function'. Below this is a table with 5 columns: 'act.', 'status', 'output function', and 'out mode'. The rows are labeled 'WR 1' through 'WR 8'. WR 1 and WR 5 are highlighted with yellow borders. WR 1 has 'act.' checked, 'status' OK, 'output function' Digital-3, and 'out mode' normal. WR 5 has 'act.' checked, 'status' OK, 'output function' Digital-2, and 'out mode' normal. All other WR modules have 'act.' unchecked, 'status' empty, 'output function' '/', and 'out mode' normal.

	act.	status	output function	out mode
WR 1	<input checked="" type="checkbox"/>	OK	Digital-3	normal
WR 2	<input type="checkbox"/>		/	normal
WR 3	<input type="checkbox"/>		/	normal
WR 4	<input type="checkbox"/>		/	normal
WR 5	<input checked="" type="checkbox"/>	OK	Digital-2	normal
WR 6	<input type="checkbox"/>		/	normal
WR 7	<input type="checkbox"/>		/	normal
WR 8	<input type="checkbox"/>		/	normal

Permanent memory

[HEMS Configurator](#) → settings page → save parameters

After parameters modification, it is necessary to save changes to the permanent memory since at startup RDC Charger always reads parameters from the permanent memory.



Backup / restore to PC

HEMS Configurator allows you to backup and restores all parameters to PC.

Phase alignment and limiter settings

Under limiter page set correct phase order to align phases of each device. Set correct main fuse limit [A] to protect the main grid fuse from over current. Check devices that can be managed by limiter and set correct limiter priority. Choose from no limiter, limit last, limit second, limit first. Max expected device current consumption is dynamically calculated and does not need to be set. In case device is an EV charging station, manually set max current for this device.