

Battery Monitoring System

(Battery monitoring system for larger UPS systems)

BTMS TOUCH DISPLAY MANUAL

(BM-HMI)

Table of content

Table of content	2
1. BTMS 7" HMI Touch display.....	3
2. Touch Panel User Interface	5
Data center overview.....	5
UPS overview	6
String detailed view	7
Settings	9
Alarm indications	11

1. BTMS 7" HMI Touch display

Order code: BM-HMI

Highlights & Features




- 7" capacitive touch screen
- Supports up to:
- 32 UPSs (32 BM-C)
- 1024 strings (32 BM-C × 32 BM-SS)
- 122.880 batteries (32 BM-C × 32 BM-SS × 120 BM-CS)

Technical specification

Power supply	24 VDC, 5 W max	
Size	7"	
Resolution	1024 × 600	
Colors	65 k, 16-bit RGB	
Communication	RS 485	
	1200 - 115200 bps	
Dimensions	Width	184 mm
	Height	118 mm
	Depth	15 mm
	Max depth	23 mm


Wiring



Mounting


- On the wall
- On the cabinet

Dimensions



2. Touch Panel User Interface

Data center overview




1	UPS status (disabled = dimmed, OK = blue text, error = red border)
	Status: OK, disabled
	U: UPS average voltage [V]
	I: UPS total current [A]
	SOC: UPS average SOC [%]
	Touch → go to UPS overview screen
2	UPS and String settings (Password protected: 3141)
3	To first entry
4	Previous 8 entries
5	Displayed indexes
6	Next 8 entries

7 To last entry

*Buttons 3 to 7 are the same on UPS overview screen and String detailed view screen


UPS overview



1	Displayed UPS Index
2	Selected UPS data (Uu: UPS voltage [V], Iu: UPS current [A], Status: OK/disabled, SOC [%])
3	String status (disabled = dimmed, OK = blue text, error = red border)
	Status: OK, disabled
	U: String average voltage [V]
	I: String total current [A]
	SOC: String average SOC [%]
	Touch → go to String detailed view

4	Touch → go to Main screen
5	Touch → go to Previous screen
6	Touch → select Previous UPS
7	Touch → select Next UPS

String detailed view



1	Displayed String Index
2	Selected string data
	Us (String voltage) [V]
	Is (String current) [A]
	String status (disabled, OK, error)
	SOC [%]
	Balance [%]

String state (floating charge, equalizing charge, discharge, idle, abnormal)
Temperature (ambient temperature) [°C]
RH (relative ambient humidity) [%]
DI DO: Digital input and Digital output status (0=disabled, 1=enabled)

3	Cell data
	Icon (disabled = gray X + dimmed, OK = green ✓, error = red X) and index
	Uc (cell voltage) [V]
	Rc (cell resistance) [m ohm]
	T (cell temperature) [°C]
	SOC (Cell state of charge) [%]
	SOH (Cell state of health [%])
	Rem.h (remaining cell time in hours)
4	Touch → go to Main screen
5	Touch → go to Previous screen
6	Touch → select Previous String
7	Touch → select Next String


Settings

UPS settings



1	Touch → go to String settings
2	Touch → change UPS default name
3	Touch → go to Previous screen
4	Touch → save settings
5	Touch → revert settings to defaults

String settings



1	Touch → go to UPS settings
2	Touch → change String default name
3	Touch → go to Previous screen
4	Touch → save settings
5	Touch → revert settings to defaults

Alarm indications

Battery Monitoring System

!

1

robotina

UPS	Status	U [V]	I [A]	SOC
UPS 1	OK	528.47	77.28	25
UPS 2	OK	540.10	-88.56	79
UPS 3	OK	745.93	-39.97	44
UPS 4	OK	763.68	28.43	83
UPS 5	OK	561.18	-109.91	28
UPS 6	OK	452.90	-83.42	66
UPS 7	OK	554.09	-104.03	83
UPS 8	OK	466.29	198.26	2

<<

<

1 - 8

>

>>

↶

2<

>

⏏

v 2.2.0

- | | |
|---|---------------------------------------|
| 1 | Common alarm indicator |
| 2 | Red border → shows where is the alarm |

The information in this manual is subject to change without notice. Robotina assumes no responsibility for any errors that may appear in this document.

In no case is Robotina liable for incidental or consequential damages arising from the use of this manual or the software or hardware described in this document.

This document may not be reproduced or copied without the written permission of Robotina, and the contents may not be given to a third party or used for any unauthorized purpose.