

# Battery Monitoring System

(Battery monitoring system for larger UPS systems)

## METHOD OF STATEMENT FOR INSTALLATION AND COMMISSIONING

## Table of content

1	BTMS Installation.....	4
1.1	Base System.....	4
1.1.1	Install BM-CS.....	4
1.1.2	Install BM-HS .....	5
1.1.3	Install BM-SS .....	5
1.1.4	Install BM-GW.....	5
1.1.5	Install BM-PS.....	6
1.1.6	Install BM-MC .....	6
1.1.7	Install BM-HMI.....	6
1.1.8	Install BM-TH .....	7
1.2	Power ON.....	7
2	BTMS commissioning.....	8
2.1	General settings.....	8
2.1.1	Network settings .....	8
2.1.2	NTP settings.....	9
2.1.3	Time settings.....	9
2.1.4	Users Setting.....	10
2.1.5	SMTP settings .....	10
2.1.6	SMS notifications .....	11
2.1.7	Modbus server.....	11
2.1.8	Project settings .....	11
2.2	Adding string and battery sensors.....	12
2.2.1	Assign string sensor to string.....	13
2.2.2	Assign string to UPS .....	14
2.2.3	Adding BM-MC, BM-LC and BM-TH.....	14
2.2.4	Validate Configuration.....	16
2.2.5	Check Settings.....	17
2.3	String and Battery sensors settings .....	18
2.3.1	Alarm settings .....	18
2.3.2	Resistance settings.....	20
2.3.3	Balancing settings.....	20
2.3.4	Cell settings.....	21
2.3.5	Hall Setting .....	21
2.3.6	Voltage Measurement .....	22
2.3.7	Configuration file .....	23
3	Troubleshooting.....	25



# 1 BTMS Installation

Following steps to be done before start installation:

- Disconnect the UPS from batteries by switch off battery breaker
- Break string to small segments where total voltage doesn't reach 50 V
- Provide a place to install BTMS panel which includes below
- BM-PS in (Power supply)
- BM-GW (Gateway)
- BTMS LAN switch (Network switch)
- BM-MC (Master controller)
- BM-HMI (and communication adapter CAD-232-A2-IQ)


Provide space to install below component on the battery cabinet

- BM-SS (String sensor)
- BM-CS (Cell sensor)
- BM-HS (Hall sensor)


## 1.1 Base System

### 1.1.1 Install BM-CS

- Connect red / black wires to battery terminals (Use original cables as they are)




- Mount on battery with supplied 3M double sided stickers
- Plug in red / black battery cable connector in
- Connect the sensors with included white RJ9-RJ9 cables
- 1<sup>st</sup> OUT port (right) to 2<sup>nd</sup> IN port (left),
- 2<sup>nd</sup> OUT port (right) to 3<sup>rd</sup> IN port (left),



- Max 60 BM-CS in one line


### 1.1.2 Install BM-HS

- Unscrew split core and put around + wire from UPS to string
- Arrow is pointing from UPS to 1st battery



### 1.1.3 Install BM-SS

- Mount on DIN rail near the 1st string battery
- Connect BM-HS with included 4-pin flat cable
- Connect 1st battery BM-CS with included white RJ9-RJ9 cable
- Connect 1st battery BM-CS of second line (if needed)
- Power supply (+24 Vdc) from battery monitoring panel




### 1.1.4 Install BM-GW

- Mount in distribution cabinet on DIN rail with the included bracket
- Install BTMS LAN switch
- Mount in distribution cabinet or LAN cabinet
- Plug the power supply into the appropriate socket
- Connect LAN cables to BM-GW

- Pull the LAN cables to the BM-SS but do not connect them to the LAN switch (Properly mark which cable goes to which BM-SS)


### 1.1.5 Install BM-PS

- Check that the BM-PS capacity (3.8 A) is sufficient for all devices powered by the PS power supply
- If the consumption exceeds the capacity of the power supply divide the consumers into groups and uses several power supplies
- Make sure that circuit breaker is switched OFF
- Mount BM-PC on DIN rail in distribution cabinet
- Connect AC L & N terminals
- Connect DC + & - terminals to
  - All BM-SS
  - BM-GW



### 1.1.6 Install BM-MC


- Mount in distribution cabinet on DIN rail
- Connect DC power supply +24 V & GND terminals to + & - of power supply terminals
- Connect LAN cable to BTMS LAN switch



### 1.1.7 Install BM-HMI

- Mount CAD-232-A2-IQ adapter on DIN rail next to BM-MC
- Ensure that the connecting cable (short RJ9 to RJ9) to the BM-MC is correctly inserted
- Connect BM-MC COM 2 port with CAD-232-A2-IQ adapter bottom port (it doesn't matter which one)
- Connect BM-HMI A & B terminals to CAD-232-A2-IQ A & B terminals

- Connect BM-HMI +24 V & GND terminals to + & - BM-PS terminals



### 1.1.8 Install BM-TH

- Mount BM-TH on wall next to string
- Pull communication bus and power supply to BM-MC - do not connect to BM-TH
- Communication bus must follow rules for RS-485 wiring
  - Bus line (no branching)
  - Use twisted pair shielded cable
  - Shield connected ONLY to one end of line
  - Terminate line with 120-ohm resistor on both side
  - Max length 1200 m




## 1.2 Power ON

- Visually inspect wiring
- Power on BM-PS circuit breaker
- Check that all devices that are powered by the power adapter are turned on and are working stably (the LED indicators are lit continuously)

## 2 BTMS commissioning


- Connect the laptop to the BTMS LAN switch
- Set the IP on the laptop to 192.168.10.20
- Open the address 192.168.10.1 in the Internet browser
- Login with default username (admin) and default password (bmgw!admin)



### 2.1 General settings


#### 2.1.1 Network settings

- Select Settings - General tab
- Set the parameters for the WAN interface



## 2.1.2 NTP settings

- if necessary / requested set the parameters for an additional NTP (Network Time Protocol) server




The screenshot shows the 'NTP settings' section of the Robotina Data Center settings. It includes:

- Network settings:** A table showing Adapter (LAN/WAN), Mode (fixed), IP, Subnet, Gateway, and DNS.
- NTP settings:**
  - Custom NTP:** A table with columns Host, Port, and Enabled. One entry is shown with the port set to 123.
  - Default NTP pools (ENABLED):** A list of hosts: ntp.ubuntu.com, 0.ubuntu.pool.ntp.org, 1.ubuntu.pool.ntp.org, and 2.ubuntu.pool.ntp.org.
- Time settings:** A table for setting Time and Date.

## 2.1.3 Time settings

- Set the desired time zone




The screenshot shows the 'Time settings' section of the Robotina Data Center settings. It includes:

- Time settings:** A table for setting Time and Date.
- Timezone:** A dropdown menu set to Europe/Ljubljana.
- Users:** A table listing users with their full names, administrator status, phone numbers, and email addresses.
- SMTP settings:** A table for configuring SMTP settings.

## 2.1.4 Users Setting

- Change (and remember!) the admin password
- Add users



The screenshot shows the 'Data Center - Settings' interface. At the top, there are tabs for 'Real-time data', 'History data', 'Discharge data', 'Alarm', and 'Settings'. A user 'The Main Admin User' is logged in. The main content area has three sections:

- Time settings**: Shows current time (18:10:09) and date (06/07/2022), with edit buttons.
- Users**: A table listing three users:
 


User	Full name	Administrator	Phone number	E-mail
admin	The Main Admin User	<input checked="" type="checkbox"/>		razvoj@3-port.si
goran	Goran Kocjancic	<input checked="" type="checkbox"/>	041379313	goran.kocjancic@robotina.com
devid	Devid Palcic	<input checked="" type="checkbox"/>		
- SMTP settings**: A table for configuring an SMTP server:
 

Host	Port	From E-mail	Security	Username

At the bottom, there are copyright and version information: © Robotina d.o.o all rights reserved. 1.0.dev / 1.0.64.dev / 1.0.dev

## 2.1.5 SMTP settings

- Set the parameters for the SMTP (e-mail) server



The screenshot shows the 'Data Center - Settings' interface with the 'Settings' tab selected. The main content area has four sections:

- SMTP settings**: A table for configuring an SMTP server:
 

Host	Port	From E-mail	Security	Username
- SMS notifications**: A message stating 'Your user does not have an associated phone number.' with a 'Test SMS' button.
- Project settings**: A table for project metadata:
 


Project name	Company	URL	Owner
- Data Export**: A table for managing data exports:
 

File	Size	Time
No data exports available		

At the bottom, there are copyright and version information: © Robotina d.o.o all rights reserved. 1.0.dev / 1.0.64.dev / 1.0.dev

## 2.1.6 SMS notifications

- Test SMS messaging




The screenshot shows the 'Data Center - Settings' page of the BTMS system. The top navigation bar includes tabs for 'Real-time data', 'History data', 'Discharge data', 'Alarm', and 'Settings'. The 'Settings' tab is active. On the left, a sidebar menu shows 'Data Center' expanded, with 'UPS 1' and 'String 1/1' listed under it. The main content area contains several sections: 'SMTP settings' (with an 'Edit' button and a table for Host, Port, From E-mail, Security, and Username), 'SMS notifications' (with a 'Test SMS' button and a message stating 'Your user does not have an associated phone number.'), 'Project settings' (with 'Edit' and 'Delete logo' buttons and a table for Project name, Company, URL, and Owner), and 'Data Export' (with a 'New data export' button and a table for File, Size, and Time, showing 'No data exports available'). The bottom of the page includes copyright information ('© Robotina d.o.o all rights reserved.') and a footer note ('1.0.dev / 1.0.64.dev / 1.0.dev').

## 2.1.7 Modbus server

- Edit Modbus settings

## 2.1.8 Project settings


- Set project information
- The project name is displayed as root in the tree menu
- You can also change the logo that appears above the tree menu



This screenshot is identical to the one above, showing the 'Data Center - Settings' page of the BTMS system. It displays the same sections: 'SMTP settings', 'SMS notifications', 'Project settings', and 'Data Export'. The 'Project settings' section is currently active, showing an 'Edit' button and a table for Project name, Company, URL, and Owner. The bottom of the page includes the same copyright and footer information.

## 2.2 Adding string and battery sensors

- Select Settings - Configuration tab
- Connect a string sensor (always only one new-one at a time)
- In the New unassigned BM-SS table (below main table) OK should appear for COM Status and HALL



The screenshot shows the Data Center Configuration interface. At the top, there are tabs for Real-time data, History data, Discharge data, Alarms, and Settings. Under Settings, the Configuration tab is selected. Below the tabs, there's a sub-menu with 'String' and 'UPC'. The main area displays the 'BM-SS String monitor' configuration table. This table has columns for Index, Name, UPC, Name, COM Status, Batteries, Hall, and several rows for indices 1 through 12. Below this table is a button labeled 'Assign BM-SS'. At the bottom of the screen, there's a 'New unassigned BM-SS' table with columns for COM Status, Batteries, and Hall, and a row for 'OK'.

- To set the battery sensors press the Configure cells button
- In Cell sensor addressing dialog box
- Press Auto-sensing
- Wait that Address searching status change to 3
- Check whether all battery sensors have been found
- If all sensors found then confirm with the Check & Write button
- If the number of sensors found does not match the expected check sensor
- Cabling and repeat Auto-sensing

The screenshot shows the 'Cell Sensor addressing - String 0' dialog box open over a table of sensor data. The dialog box contains fields for 'Auto-sensing' and 'Check & Write', and displays 'Address searching status: 3', 'Quantity of COM1 cells: 2', and 'Quantity of COM2 cells: 0'. The main interface includes tabs for 'General', 'Configuration', and 'Diagnostics', and buttons for 'EditString', 'EditUPS', 'Move BM-SS', 'Configure cells', 'Move BM-TH', and 'EN-LC AUTO-address'.


## 2.2.1 Assign string sensor to string

- Press Assign BM-SS
- In Assign BM-SS dialog box select to which string BM-SS should be assigned

The screenshot shows the 'Assign BM-SS' dialog box open over a table of sensor data. The dialog box has fields for 'From' (set to 'Unassigned') and 'To' (set to 'String 1'). It also has 'Cancel' and 'Save' buttons. The main interface includes tabs for 'General', 'Configuration', and 'Diagnostics', and buttons for 'EditString', 'EditUPS', 'Move BM-SS', 'Configure cells', 'Move BM-TH', and 'EN-LC AUTO-address'.

## 2.2.2 Assign string to UPS

- In main table select row
- Press Edit UPS
- In Edit UPS dialog
  - Select UPS ID
  - Set name for UPS
- Subsequent movement or reassignment of BM-SS sensors to another string and automatic reconfiguration of battery sensors is also possible
- Repeat the process for all string sensors



The screenshot shows the Data Center - Configuration interface with the UPS tab selected. A modal dialog titled "Edit UPS" is open, showing the current UPS ID as "1 .. NewUPS" and the name as "UPS 08". Below the main table, there are two smaller tables for BM-SS and BM-TH assignments.

String		UPS		BM-SS String inverter			BM-MC Master controller IPAD: null			BM-LC Auxiliary digital IO		
Index	Name	UPS	Name	CON Status	Batteries	Hall	CON Status	Temperature	Humidity	Status	DI	DO
1	String 01			OK	OK	OK	-	-	-	-	-	-
2	String 02			-	-	-	-	-	-	-	-	-
3	String 03			-	-	-	-	-	-	-	-	-
4	String 04			-	-	-	-	-	-	-	-	-
5	String 05						-	-	-	-	-	-
6	String 06						-	-	-	-	-	-
7	String 07						-	-	-	-	-	-
8	String 08						-	-	-	-	-	-
9	String 09						-	-	-	-	-	-
10	String 10						-	-	-	-	-	-
11	String 11						-	-	-	-	-	-
12	String 12						-	-	-	-	-	-

New unassigned BM-SS			New unassigned BM-TH		
CON Status	Batteries	Hall	CON Status	Temperature	Humidity
-	-	-	-	-	-

Buttons at the bottom include: EditString, EditUPS, Move BM-SS, Configure BM-SS, Move BM-TH, Assign BM-TH, Assign BM-SS, Configure BM-TH, and Assign BM-SS.

## 2.2.3 Adding BM-MC, BM-LC and BM-TH

- Select Settings - Configuration tab
- Select BM-MC controller in main table 1st row right side
- Press BM-LC Auto-address to discover connected BM-LC IO modules
- If the modules are connected correctly, the statuses in the right 3 columns should change

BM-SS String monitor							BM-TH Temperature and humidity sensors			BM-LC Auxiliary digital IO		
Index	Name	UPS	Name	COM Status	Batteries	Hall	COM Status	Temperature	Humidity	Status	DI	DO
1	String 01	1	UPS 01	OK	OK	OK	-	-	-	-	-	-
2	String 02			-	-	-	-	-	-	-	-	-
3	String 03			-	-	-	-	-	-	-	-	-
4	String 04			-	-	-	-	-	-	-	-	-
5	String 05			-	-	-	-	-	-	-	-	-
6	String 06			-	-	-	-	-	-	-	-	-
7	String 07			-	-	-	-	-	-	-	-	-
8	String 08			-	-	-	-	-	-	-	-	-
9	String 09			-	-	-	-	-	-	-	-	-
10	String 10			-	-	-	-	-	-	-	-	-
11	String 11			-	-	-	-	-	-	-	-	-
12	String 12			-	-	-	-	-	-	-	-	-

New unassigned BM-SS			New unassigned BM-TH		
COM Status	Batteries	Hall	COM Status	Temperature	Humidity
-	-	-	-	-	-

© Robotina d.o.o. All rights reserved (except for included open-source).

1.1.4.v1 / 1.2.0.Beta.v1 / 1.4

- Connect BM-TH temperature and humidity sensor (only one new sensor at a time)
- The data of the connected sensor should appear in the New unassigned BM-TH table below the main table

BM-SS String monitor							BM-TH Temperature and humidity sensors			BM-LC Auxiliary digital IO		
Index	Name	UPS	Name	COM Status	Batteries	Hall	COM Status	Temperature	Humidity	Status	DI	DO
1	String 01	1	UPS 01	OK	OK	OK	-	-	-	-	-	-
2	String 02			-	-	-	-	-	-	-	-	-
3	String 03			-	-	-	-	-	-	-	-	-
4	String 04			-	-	-	-	-	-	-	-	-
5	String 05			-	-	-	-	-	-	-	-	-
6	String 06			-	-	-	-	-	-	-	-	-
7	String 07			-	-	-	-	-	-	-	-	-
8	String 08			-	-	-	-	-	-	-	-	-
9	String 09			-	-	-	-	-	-	-	-	-
10	String 10			-	-	-	-	-	-	-	-	-
11	String 11			-	-	-	-	-	-	-	-	-
12	String 12			-	-	-	-	-	-	-	-	-

New unassigned BM-SS			New unassigned BM-TH		
COM Status	Batteries	Hall	COM Status	Temperature	Humidity
-	-	-	OK	23.1 °C	44.2 %

© Robotina d.o.o. All rights reserved (except for included open-source).

1.1.4.v1 / 1.2.0.Beta.v1 / 1.4

- Use the Assign BM-TH button to determine which string the sensor belongs to
- Repeat for all BM-TH sensors

Screenshot of the Data Center - Configuration interface showing the configuration of a BM-SS String master. The main table lists 12 strings connected to UPS 01, with various status indicators (OK, N/A) and sensor values (Temperature: 23.3 °C, Humidity: 41.5 %). Buttons for 'Edit String', 'Edit UPS', 'Move BM-SS', 'Configure cells', 'Move BM-TH', and 'BM-LC Auto-address' are visible. A message box at the bottom right indicates a successful move operation.

Index	Name	UPS	Name	COM Status	Batteries	Hall	BM-MC Master controller NAD: 30629		
							COM Status	Temperature	Humidity
1	String 01	1	UPS 01	✗	OK	OK	OK	23.3 °C	41.5 %
2	String 02			-	-	-	-	-	-
3	String 03			-	-	-	-	-	-
4	String 04			-	-	-	-	-	-
5	String 05			-	-	-	-	-	-
6	String 06			-	-	-	-	-	-
7	String 07			-	-	-	-	-	-
8	String 08			-	-	-	-	-	-
9	String 09			-	-	-	-	-	-
10	String 10			-	-	-	-	-	-
11	String 11			-	-	-	-	-	-
12	String 12			-	-	-	-	-	-


## 2.2.4 Validate Configuration

- Check whether the data in the main table reflect the actual desired state
- Confirm the configuration with the Apply configuration button above the table

Screenshot of the Data Center - Configuration interface showing the configuration of a BM-SS String master. The main table lists 12 strings connected to UPS 13, with various status indicators (OK, N/A) and sensor values (Temperature: 22.7 °C, Humidity: 57.5 %). Buttons for 'Edit String', 'Edit UPS', 'Move BM-SS', 'Configure cells', 'Move BM-TH', and 'BM-LC Auto-address' are visible. A message box at the bottom right indicates a successful move operation.

Index	Name	UPS	Name	COM Status	Batteries	Hall	BM-MC Master controller NAD: 20915		
							COM Status	Temperature	Humidity
1	String 01	1	UPS 13	✗	OK	OK	OK	22.7 °C	57.5 %
2	String 02	1	UPS 13	✗	OK	OK	OK	22.6 °C	58.4 %
3	String 03	1	UPS 13	✗	OK	OK	OK	22.6 °C	57.2 %
4	String 01	2	UPS 14	✗	OK	OK	OK	22.8 °C	57.6 %
5	String 02	2	UPS 14	✗	OK	OK	OK	22.6 °C	58.4 %
6	String 03	2	UPS 14	✗	OK	OK	OK	22.8 °C	57.4 %
7	String 01	3	UPS 15	✗	OK	OK	OK	23.0 °C	56.4 %
8	String 02	3	UPS 15	✗	OK	OK	OK	23.0 °C	57.1 %
9	String 09	-		-	-	-	-	-	-
10	String 10	-		-	-	-	-	-	-
11	String 11	-		-	-	-	-	-	-
12	String 12	-		-	-	-	-	-	-

- The tree menu on the left side should refresh and reflect the actual status of the UPS and strings connected to the BM-GW



The screenshot shows the Data Center - Real Time Data interface. In the top right corner, there is a user profile for "The Main Admin User" and a "BTMS" button. The main content area displays real-time data for three UPS units (UPS 13, UPS 14, UPS 15) in a table. Below the table is a bar chart for voltage levels.

UPS	Status	Voltage	Current	SoC
UPS 13	OK	626.74 V	0.00 A	100 %
UPS 14	OK	626.48 V	4.72 A	100 %
UPS 15	OK	572.67 V	0.00 A	100 %

**Voltage**

Legend: HIGH (top), LOW (middle), 0 (bottom).

UPS 13, UPS 14, UPS 15

© Robotina d.o.o all rights reserved (except for included oss software).


1.0 / 1.0.64 / 1.5

## 2.2.5 Check Settings

- Switch the laptop to the facility network
- Set the IP on the laptop according to the requirements for the facility LAN
- Use the Internet browser to go to the address you set for the WAN connection

## 2.3 String and Battery sensors settings

- To set up an individual BTMS string sensor, just select it in the tree structure on the left and select the Settings view.



**Alarm settings**

	Alarm trigger threshold	Alarm clear threshold	SMS	E-mail	DO
Enable alarms	<input checked="" type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String current charge limit	200.0 A	190.0 A	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String current discharge limit	-200.0 A	-190.0 A	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String voltage high limit	28.8 V	27.4 V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String voltage low limit	21.6 V	22.6 V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String SoC low limit	30 %	40 %	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Hall alarm enable	<input checked="" type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell voltage high limit	14.40 V	13.70 V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell voltage low limit	10.80 V	11.30 V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell resistance high limit	25.00 mΩ	20.00 mΩ	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell SoC low limit	50 %	60 %	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell SoH low limit	60 %	70 %	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell temperature high limit	50 °C	48 °C	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**Resistance settings**


	Resistance measurement interval	
	1h ~ 120h	1 h

**Balancing settings**

	<input type="checkbox"/>

### 2.3.1 Alarm settings

- The conditions for triggering and automatic alarm reset are set for the string and for all batteries within the string.
- Editing of the settings is enabled with the Edit button above the table.



**Alarm settings**

	Alarm trigger threshold	Alarm clear threshold	SMS	E-mail	DO
Enable alarms	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
String current charge limit	200.0 A	190.0 A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
String current discharge limit	-200.0 A	-190.0 A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
String voltage high limit	28.8 V	27.4 V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
String voltage low limit	21.6 V	22.6 V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
String SoC low limit	30 %	40 %	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Hall alarm enable	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Cell voltage high limit	14.40 V	13.70 V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Cell voltage low limit	10.80 V	11.30 V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Cell resistance high limit	25.00 mΩ	20.00 mΩ	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Cell SoC low limit	50 %	60 %	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Cell SoH low limit	60 %	70 %	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Cell temperature high limit	50 °C	48 °C	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>


**Resistance settings**

	Resistance measurement interval	
	1h ~ 120h	1 h

**Balancing settings**

	<input type="checkbox"/>

- Limit values are set in the left part of the table, and the action that the alarm triggers is set in the right part. The action can be sending an SMS or/and e-mail message or/and triggering a digital output.
- Use the Write button to use the entered changes. The “Cancel” button cancels all changes.
- The Recommend button presets some alarm parameters depending on the connected batteries and the used Hall sensor.



The screenshot shows the 'Alarm settings' section of the String Settings software. A 'Recommend' dialog box is open, showing recommended parameters for a battery cell:

Cell nominal voltage	12 V
Cell type	200 A
Cell count	2


The main table lists various alarm thresholds for the string, such as:

Alarm trigger threshold	Alarm clear threshold	SMS	E-mail	DO
String current charge limit	200.0 A	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String current discharge limit	-200.0 A	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String voltage high limit	28.0 V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String voltage low limit	21.0 V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
String SOC low limit	30 %	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell alarm enable		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell voltage high limit	14.40 V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell voltage low limit	10.80 V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell resistance high limit	25.00 mΩ	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell SOC low limit	90 %	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell Suct low limit	40 %	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cell temperature high limit	50 °C	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

- The proposed values can then be further adapted to the requirements and entered.

## 2.3.2 Resistance settings


- Here we set the battery resistance measurement frequency.



The screenshot shows the 'Resistance settings' section of the BTMS web interface. The 'Resistance measurement interval' dropdown is open, displaying various options for how often to measure impedance. The '1h - 120h' option is currently selected. Other options include 'not to measure impedance actively', 'once a week', 'once a month', 'once every two months', and 'once every three months'. Below this, there are sections for 'Balancing settings' (with an 'Enable balancing' checkbox checked) and 'Cell settings' (listing parameters like Cell capacity, Cell nominal voltage, Internal resistance reference, etc.).

## 2.3.3 Balancing settings


- Battery balancing can be enabled or disabled. If balancing is enabled, set the threshold value at which balancing is triggered and the balancing execution interval.



The screenshot shows the 'Balancing settings' section of the BTMS web interface. The 'Enable balancing' checkbox is checked, and the 'Target balance' is set to 99.0%. Below this, there are sections for 'Cell settings' (listing parameters like Cell capacity, Cell nominal voltage, Internal resistance reference, etc.) and 'Hall settings' (with a 'Hall sensor type' dropdown set to 200 A). At the bottom, there is a 'Voltage measurement' section.

### 2.3.4 Cell settings

- For the proper functioning of battery status monitoring, it is necessary to specify what batteries are used in the string.



String Settings

The Main Admin User BTMS Battery Monitoring System

Cell settings

Cell capacity	10 Ah
Cell nominal voltage	12 V
Internal resistance reference	14.50 mΩ
Internal resistance correction	0.60 mΩ
Cut-off voltage	10.80 V
Recovery voltage	12.68 V
Float voltage	13.38 V
Float current	2.00 A

Hall settings


Voltage measurement

Configuration file

© Robotina d.o.o. All rights reserved (except for included oss software). L.1.dev / L.0.04.dev / L.4

### 2.3.5 Hall Setting

- Select the sensor used from the values offered.



String Settings

The Main Admin User BTMS Battery Monitoring System

Cell settings

Cell capacity	10 Ah
Cell nominal voltage	12 V
Internal resistance reference	14.50 mΩ
Internal resistance correction	0.60 mΩ
Cut-off voltage	10.80 V
Recovery voltage	12.68 V
Float voltage	13.38 V
Float current	2.00 A

Hall settings


Voltage measurement

Configuration file

© Robotina d.o.o. All rights reserved (except for included oss software). L.1.dev / L.0.04.dev / L.4


The Zero calibration button is used to calibrate the Hall sensors.

It is important to ensure that during calibration the string current is 0 A




### 2.3.6 Voltage Measurement

- The string sensor allows 2 ways of measuring the string voltage: as the sum of the voltage of the batteries in the string or directly. Since we have to work with dangerously high voltage when measuring the voltage directly, it is recommended to use the summation of the voltage of individual batteries where possible.




## 2.3.7 Configuration file

- It is possible to easily save the string sensor settings to a file.



- And reading all the instructions from this one.



- 
- If we drag and drop the saved file onto the settings table, only the parameters that are in the table will be entered from the file.

### 3 Troubleshooting

If you are having problems with the system, try the appropriate solutions below. This may fix a system error that is the result of one of the most common system failures or installation mistakes. In any case, our technical support will be able to help you, it is at [in http://support.robotina.com](http://support.robotina.com).

By trying the solutions listed below, our technical support will also be more effective in identifying errors and will help you more effectively.

The power supply and the power supply of all components are connected correctly

Communication cables are properly connected (it is best to check each one step by step)

Check that the hall sensor is facing correctly (there is an arrow on it showing the direction of the electric current)

Check LED on Cell sensor and String master (is green breathing mode or constant red)

One of the possible causes of malfunction may also be incorrect initial system configuration.

The initial configuration of the system can only be done by an authorized person! Contact an authorized person for any problems.

**Robotina Help Desk in <http://support.robotina.com>**

