Robotina d.o.o.
OIC Hrpelje 38
SI-6240 Kozina
Slovenia

1. Manual Time Settings

If the BM-GW does not have access to the NTC Server (Internet), it is necessary to disable date and time synchronization via the NTP server and set the date and time manually.

1. Disable NTP

