
Robotina d.o.o.
OIC Hrpelje 38
SI-6240 Kozina
Slovenia

BM-GW WEB UI


- Demo: BTMS BM-GW WEB UI demo
- User: demo
- Pass: demo

Log-in




1st time log in:

- Connect Ethernet 2 port to facility LAN
- Connect PC to Ethernet 1 port (standard Ethernet cable between PC and BM-GW Ethernet 1 port)
- For PC Ethernet connection set fixed IP 192.168.10.200.
- Use the Internet browser to go to https://192.168.10.1
- Log in as:
  - user: admin
  - password: bmgw!admin
- Check the WAN IP address on the Data center - Settings page and set it if necessary



- Connect the PC to the facility LAN and go to the https://IP address of the WAN port

General description




1	Pages tabs

2	Data center tree structure
3	Page data


Data center

Real-time data




1	Tabular display of data for the Data Center
2	Select a parameter for the graphic display
3	Graphic bar-graph data display for the data center

Discharge data




1	Discharge events table
2	String time-plot for discharge event
3	Cell time-plot for discharge event

String time-plot for discharge event




Cell time-plot for discharge event




1	Cell selection

Alarm




1	Alarms sub-page selection
2	Alarms table

E-mails




SMS




Settings


Network settings, NTP settings



Time settings, Users




SNMP settings, SMS notifications, Project settings, Data export




UPS


Real-time data




History data




Discharge data




String time-plot



Cell time-plot




Alarm




String

Real-time data

String



String - Real Time Data - String
https://192.168.0.29/gui/data_center/ups/string/rt_data/string.html?ups=ups_01&string=string_01_01
Real-time data
History data
Discharge data
Alarm
Settings
The Main Admin User
BTMS
Battery Monitoring System
Data Center
UPS 1
String 1/1
String
Cells
Download
String
Status
Voltage
Current
SoC
Balance
Ambient temperature
Ambient humidity
#01
OK
217.89 V
0.00 A
100 %
98,34 %
24.0 °C
55 %
Voltage
HIGH
LOW
#004 : 13.668 V
15 V
10 V
0
#001
#002
#003
#004
#005
#006
#007
#008
#009
#010
#011
#012
#013
#014
#015
#016
© Robotina d.o.o all rights reserved.
1.0.dev / 1.0.64.dev / 1.0.dev

Cells



String - Real Time Data - Cells
https://192.168.0.29/gui/data_center/ups/string/rt_data/cells.html?ups=ups_01&string=string_01_01
Real-time data
History data
Discharge data
Alarm
Settings
The Main Admin User
BTMS
Battery Monitoring System
Data Center
UPS 1
String 1/1
String
Cells
Show 10 entries
Download
Cell
Status
Voltage
Resistance
Temperature
SoC
SoH
#001 OK 13.611 V 18.036 mΩ 300.0 °C 100 % 76 %
#002 OK 13.502 V 16.718 mΩ 300.0 °C 100 % 79 %
#003 OK 13.506 V 16.674 mΩ 300.0 °C 100 % 79 %
#004 OK 13.666 V 15.875 mΩ 300.0 °C 100 % 81 %
#005 OK 13.725 V 15.655 mΩ 300.0 °C 100 % 82 %
#006 OK 13.529 V 15.439 mΩ 300.0 °C 100 % 82 %
#007 OK 13.703 V 15.058 mΩ 300.0 °C 100 % 83 %
#008 OK 13.512 V 18.096 mΩ 300.0 °C 100 % 76 %
#009 OK 13.655 V 15.747 mΩ 300.0 °C 100 % 82 %
#010 OK 13.611 V 15.647 mΩ 300.0 °C 100 % 82 %
Showing 1 to 10 of 16 entries
Previous
1
2
Next
© Robotina d.o.o all rights reserved.
1.0.dev / 1.0.64.dev / 1.0.dev

History data


String




Cells




Discharge data




String time-plot




Cell time-plot



Alarm



Settings



Enable for which alarm SMS / e-mail will be sent.