

Temperature & Humidity monitoring

BM-TH sensors continuously measure temperature and humidity. Data is logged and used for predictive maintenance, thermal risk detection, and warranty validation. Communication is via RS485 (Modbus).

Content in preparation. Please check back soon.