


Mobile GUI

The mobile GUI allows hotel guests easy and intuitive control of the room. No app installation is required; everything operates through a web application optimized for smartphones.

The link for accessing the application is provided as a QR code on the touch panel in the room. The link automatically change when the guest in the room is replaced, ensuring that former guests can no longer control the room.




- 1** QR code link for the mobile GUI web page. To manage the room, scan the code with a smartphone. The website address and QR code automatically change when a new guest checks into the room, preventing former guests from controlling the room.







The image shows a mobile application interface for a hotel named "HIQ Hotel". The header section, labeled with a yellow box containing the number "1", features the hotel's logo on the left and the text "HIQ Hotel" in a large, bold, grey font. Below the name is the tagline "Where Hospitality Meets Innovation" in a smaller, blue font. The main content area, labeled with a yellow box containing the number "2", is titled "Please enter PIN code" in a light grey font. Below the title is a dark grey rectangular input field. Underneath the input field is a numeric keypad with buttons for digits 1 through 9, 0, a "C" (clear) button, and an "E" (enter) button. The keypad is arranged in a 4x3 grid. At the bottom of the screen, the text "Robotina d.o.o" is displayed in a small, purple font.

- | | |
|---|--|
| 1 | The hotel's logo can be customized to match the actual hotel. |
| 2 | PIN code entry keyboard. After entering the correct code, it automatically switches to the room control page. The "C" key is used to delete the code in case of an error, and the "E" key is for confirming the entry. |



1 Quick access buttons. When the function is active, the icon is highlighted in blue.

2	Control of devices in the room.
QUICK ACCESS BUTTONS	
	Unlocking the hotel room door.
	DND (Do Not Disturb) button. When DND is activated, MUR is automatically turned off. DND status is indicated on the panel outside the room and on the reception app.
	MUR (Make Up Room) button. When MUR is activated, DND is automatically turned off. MUR status is indicated on the panel outside the room and on the reception app.
	Button for quickly turning off all room lighting.

Setpoint

°C

22.0

slider	
text	Control of devices in the room.