



# RDC Charger

## User manual



**Robotina d.o.o.**  
OIC-Hrpelje 38 Hrpelje  
SI-6240 Kozina  
Slovenia



---

# Table of Contents

**Mobile GUI** ..... 5



# Mobile GUI

The mobile GUI allows hotel guests easy and intuitive control of the room. No app installation is required; everything operates through a web application optimized for smartphones.

The link for accessing the application is provided as a QR code on the touch panel in the room. The link automatically change when the guest in the room is replaced, ensuring that former guests can no longer control the room.



- 1** QR code link for the mobile GUI web page. To manage the room, scan the code with a smartphone. The website address and QR code automatically change when a new guest checks into the room, preventing former guests from controlling the room.

1

HIQ Hotel  
Where Hospitality Meets Innovation

Please enter PIN code

2

1 2 3


4 5 6

7 8 9

C 0 E

[Robotina d.o.o](#)





- |   |  |
|---|--|
| 1 | The hotel's logo can be customized to match the actual hotel.  |
| 2 | PIN code entry keyboard. After entering the correct code, it automatically switches to the room control page. The "C" key is used to delete the code in case of an error, and the "E" key is for confirming the entry. |




**1** Quick access buttons. When the function is active, the icon is highlighted in blue.

## 2 Control of devices in the room.

## QUICK ACCESS BUTTONS

	Unlocking the hotel room door.
	DND (Do Not Disturb) button. When DND is activated, MUR is automatically turned off. DND status is indicated on the panel outside the room and on the reception app.
	MUR (Make Up Room) button. When MUR is activated, DND is automatically turned off. MUR status is indicated on the panel outside the room and on the reception app.
	Button for quickly turning off all room lighting.

## DEVICE CONTROLS

<p>Setpoint <span style="float: right;">°C</span></p> <p style="text-align: right; font-size: 24pt; color: blue;"><b>22.0</b></p> 	Setting the desired temperature for heating or cooling for the guest.
<p>Fan limit <span style="float: right;">OFF</span></p> 