



# RDC Charger

## User manual



**Robotina d.o.o.**  
OIC-Hrpelje 38 Hrpelje  
SI-6240 Kozina  
Slovenia

---



# Table of Contents

**4G LTE USB modem for IOT linker** ..... 5



# 4G LTE USB modem for IOT linker

## for IOT-L2-2 and other our IOT linkers

Plug and play USB modem for linker LTE mobile internet.



**Note:** PIN must be removed from the SIM card.

Order code :	<b>IOT-L2-W</b>
--------------	-----------------