



RDC Charger

User manual



Robotina d.o.o.
OIC-Hrpelje 38 Hrpelje
SI-6240 Kozina
Slovenia

Table of Contents

Troubleshooting 5

Troubleshooting

| ERROR | POSSIBLE CAUSES | SOLUTION | | | |
|------------------------------|---|---|--|-----|------|
| CP positive/negative voltage | The voltage on the CP connector is out of permitted range | Check the charging cable and connector and reconnect the electric vehicle | | | |
| RCD sensor trip | Switch has detected a DC differential current | If is problem with only one vehicle, please call an authorized vehicle service. | | RAM | 2 GB |
| | Storage | 32 GB | | | |
| | Operation System | Windows 10 Home + myHIQ | | | |
| Communication | LAN | RJ45 | | | |
| | WiFi | 802.11b/g/n | | | |
| Power | Adapter | 5V 3 A | | | |
| | Battery | Optional | | | |